Originale	Sostituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
i	Info / Angle
0/AV	0
Mute	Mute / Dimmer
Up	Up
P+	CH+ / Page+
Vol +	Vol +
Right	Right

Originale	Sostituto
Vol -	Vol -
Left	Left
OK	OK
P-	CH- / Page-
Down	Down
AUX	Shift + 7
TXT	Text / Goto
Red/Picture	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/Format	Yellow / YouTube / Repeat
Blue/Audio	Blue / Prime Video / Random
Colour-	<< / Tune-
Colour+	>> / Tune+
Brightness-	I<< / Preset-
Brightness+	>>I / Preset+

Originale	Sostituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
i	Info / Angle
0/AV	0
Mute	Mute / Dimmer
Up	Up
P+	CH+ / Page+
Right	Right
Vol +	Vol +

Originale	Sostituto
Vol -	Vol -
Left	Left
OK	OK
P-	CH- / Page-
Down	Down
AUX	Shift + 7
TXT	Text / Goto
Red/Picture	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/Format	Yellow / YouTube / Repeat
Blue/Audio	Blue / Prime Video / Random
Colour-	<< / Tune-
Colour+	>> / Tune+
Brightness-	I<< / Preset-
Brightness+	>>I / Preset+

Originale	Sostituto	Originale	Sostituto
Power	Power		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
P+	CH+ / Page+		
>>	>> / Tune+		
<<	<< / Tune-		
Play	Play / Slow		
P-	CH- / Page-		
AUX	7		
TXT	Text / Goto		