Mandis shop

# Philips 996510023877

| Originale | | Sostituto | |
|---|---|---|---|
| | Power | | Power |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| SOUND | Sound | TITLE SOUND | Sound / Title |
| AUDIO SOURCE | Source Audio | LANG I/II AUDIO | Audio / Lang I/II |
| SURROUND | Surround | SURROUND | Eject / Surround |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| RADIO | Radio | PROGRAM TV/RADIO | TV/Radio / |
| HDMI SOURCE | Source/HDMI | RDS AV INPUT | AV / Input / RDS |
| AUDIO SETUP PROGRAM | Audio | HOME MENU | Menu / Home |
| | Up | | Up |
| DOUBLE BASS | Double Bass | ANGLE INFO | Info / Angle |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| DELETE | Delete | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Originale | | Sostituto | |
|---|---|---|---|
| | Down | | Down |
| BACK | Back | RETURN BACK | Back / Return |
| VOL+ | Vol + | VOL + | Vol + |
| VOL− | Vol - | VOL − | Vol - |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |

https://redcontrols.it/Philips/1672-792-telecomando-sostituzione-per-Philips-996510023877.htm