Mandis shop

LG AKB74815391

Originale		Sostituto	
	Power		Power
F	F	HOME MENU	Menu / Home
ASC(III)	ASC(III)	OPT-TOOLS SETUP	Setup / OPT /
VOL +	Vol +	VOL +	Vol +
STANDARD	Standard	LANG I/II AUDIO	Audio / Lang I/II
	Mute	DIMMER MUTE	Mute / Dimmer
–	Vol -	VOL –	Vol -
CINEMA	Cinema	LIST SMART	Smart / List
I<<	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
>>I	>>I	PRESET+	>>I / Preset+
REAR LEVEL +	Rear Level +	CH PAGE +	CH+ / Page+
WOOFER LEVEL +	Woofer Level +		Up
AUTO POWER ON	Auto Power On		Right
REAR LEVEL –	Rear Level -	CH PAGE –	CH- / Page-
WOOFER LEVEL –	Woofer Level -		Down

Originale		Sostituto	
AUTO POWER OFF	Auto Power Off		Left

https://remotecontrols.it/LG/1678987-telecomando-sostituzione-per-LG-AKB74815391.html