Mandis shop

Pioneer CU-PD046

Originale	Sostituto
Standby / On	Power
Disc 1	1
Disc 2	2
Disc 3	3
Disc 4	4
Disc 5	5
Disc 6	6
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
Random	Blue / Prime Video / Random
<<	<< / Tune-
>>	>> / Tune+
Hi-Lite	Smart / List
I<<	I<< / Preset-
>>I	>>I / Preset+
Program	TV/Radio / Program

Originale	Sostituto
Delete	Back / Return
Check	OK
Clear	Exit / Cancel / Clear

https://redcontrols.it/Pioneer/1676-501-telecomando-sostituzione-per-Pioneer-CU-PD104.htm