Mandis shop

Grandi n GOLD001

Originale		Sostituto	
MARCHE	Marche		Power
EJECT	Eject	SURROUND	Eject / Surround
	Up		Up
EFF./CLEAR	EFF./Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
	Right		Right
OK HORLOGE COMPT	OK/Horloge	OK	OK
	Down		Down
i	i	ANGLE INFO	Info / Angle
PAUSE/	Pause	STEP-FREEZE	Pause / Step / Freeze
AV	>>/AV	TUNE+	>> / Tune+
RET	<<RET	TUNE-	<< / Tune-
LECT	Play/Lect	SLOW	Play / Slow
ENR/DEP	ENR/DEP	REC MODE	Rec / Rec Mode
STOP	Stop	HOLD	Stop / Hold
1	1	TV 1	1
2	2	DVD 2	2

Originale		Sostituto	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV/VIDEO	TV / Video	PROGRAM TV/RADIO	TV/Radio /
TV/VIDEO	TV / Video	SHIFT + VIDEO 4	Shift + 4
TV/VIDEO	TV / Video	SHIFT + TV 1	Shift + 1
0	0	HDMI-SAT 0	0
ZAPPUB	Zappub	LIST SMART	Smart / List
LP	LP	OPT-TOOLS SETUP	Setup / OPT /
AV	AV	RDS AV INPUT	AV / Input / RDS
VERROUILLAGE	Verrouillage	MEDIA DISPLAY	Display / Media
SMART STOP	Smart Stop	SHIFT + HOLD	Shift + Stop /
SMART REPEAT	Smart Repeat	APP REPEAT	Green / APP / Repeat

https://remotecontrols.it/1697-881-telecomando-sostituzione-per-Grandi-GOLD001.html