Mandis shop

RC-601

Originale		Sostituto	
IN	IN		Up
IN	IN	CH	CH+ / Page+
IN	IN		Right
IN	IN	VOL	Vol+
OUT	OUT		Down
OUT	OUT	CH	CH- / Page-
OUT	OUT		Left
OUT	OUT	VOL	Vol-

Originale	Sostituto

https://remote-controls.ch/it/LAVA/1068113-27978-telecomando-di-sostituzione-per-LAVA-RC-601.html