Mandis shop

RM-SEP30

Originale	Sostituto
Power	Power
Volume+	Vol +
Music Menu	Menu / Home
Mega Bass	Sound / Title
Volume-	Vol -
Tape	5
CD/Remain	3
Tuner/Band	6
Preset +	Shift + >>I / Preset+
Tuning/Clock/Timer +	>> / Tune+
Tuner	OK
Preset -	Shift + I<< / Preset-
Tuning/Clock/Timer -	<< / Tune-
Shuffle	Smart / List
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold

Originale	Sostituto
I<<<<	I<< / Preset-
>>>>I	>>I / Preset+
Clock/Timer/Sleep Set	Sleep / Timer
Timer On/Off	Fav / Marker / PC
Repeat	Green / APP / Repeat

https://remotecontrols.it/Sony/1082-550-telecomando-sostituzione-per-Sony-RM-SEP30-146271.html