Originale	Sostituto
Eject	Eject / Surround
Power	Power
Disc	Shift + 2
Radio	Shift + 6
iPod	Shift + 3
AUX	Shift + 7
Settings	Setup / OPT /
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube /
Display	Display / Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Originale	Sostituto
8	8
9	9
Clear	Shift + Exit / Cancel / Clear
0	0
Find	Shift + Red / Netflix /
Home	Menu / Home
Surround	Shift + Eject / Surround
Options	Shift + Setup / OPT / Tools
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Exit	Exit / Cancel / Clear
Top Menu	D. Menu / Top
Pop-Up	Guide / EPG / -/--
I<<	I<< / Preset-

Originale	Sostituto	Originale	Sostituto
>>I	>>I / Preset+		
<<	<< / Tune-		
>>	>> / Tune+		
Stop	Stop / Hold		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Volume+	Vol +		
Mute	Mute / Dimmer		
Channel +	CH+ / Page+		
Volume-	Vol -		
Channel -	CH- / Page-		
Red/ Program	Red / Netflix / Search		
Green/ Bookmar	Green / APP / Repeat		
Yellow/ Thumbnail	Yellow / YouTube / Repeat		
Blue/ Zoom	Blue / Prime Video / Random		

Originale	Sostituto
Eject	Eject / Surround
Power	Power
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube /
Display	Display / Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Clear	Shift + Exit / Cancel / Clear
0	0
Find	Shift + Red / Netflix / Search

Originale	Sostituto
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Exit	Exit / Cancel / Clear
Top Menu	D. Menu / Top
Pop-Up	Guide / EPG / -/--
I<<	I<< / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
Volume+	Vol +
Mute	Mute / Dimmer

Originale	Sostituto	Originale	Sostituto
Channel +	CH+ / Page+		
Volume-	Vol -		
Channel -	CH- / Page-		
Red/ Program	Red / Netflix / Search		
Green/ Bookmar	Green / APP / Repeat		
Yellow/ Thumbnail	Yellow / YouTube / Repeat		
Blue/ Zoom	Blue / Prime Video / Random		