Originale		Sostituto		Originale		Sostituto	
POWER ON	On		Power	NIGHT	Night	ANGLE INFO	Info / Angle
POWER OFF	Off	SHIFT +	Shift + Power	M-ROOM	M-Room	SIZE ZOOM	Zoom / Size
	Mute	DIMMER MUTE	Mute / Dimmer	VOL.	Vol -	VOL	Vol -
AVR	AVR	PC FAV MARKER	Fav / Marker / PC	CH.	CH. / [≡?]	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DVD	DVD	SHIFT + DVD 2	Shift + 2		Up		Up
CD	CD	SHIFT + CD - STB 3	Shift + 3	MENU SPKR	SPKR/ Menu	HOME MENU	Menu / Home
TAPE	Tape	SHIFT + TAPE 5	Shift + 5		Left		Left
VCR VID1	VID1/ VCR	-/-- GUIDE EPG	Guide / EPG / -/--	SET	Set	TOP MENU D.MENU	D. Menu / Top
TV VID2	VID2/ TV	SHIFT + TV 1	Shift + 1		Right		Right
CBL/SAT VID3	VID3/ CBL/ SAT	SHIFT + HDMI - SAT 0	Shift + 0	DIGITAL	Digital / [≡X]	NETFLIX SEARCH	Red / Netflix / Search
VID4	VID4	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		Down		Down
AM/FM	AM/FM	SHIFT + TUNER 6	Shift + 6	DELAY NORMAL	Delay/ Normal	OPT-TOOLS SETUP	Setup / OPT /
6/8CH	6/8 CH	FORMAT PICTURE	Picture / Format	1	1	TV 1	1
SLEEP PR	Sleep	TIMER SLEEP	Sleep / Timer	2	2	DVD 2	2
TEST	Test	GOTO TEXT	Text / Goto	3	3	CD - STB 3	3
VOL.	Vol +	+ VOL	Vol +	4	4	VIDEO 4	4
PR SURR.	Surr.	SURROUND	Eject / Surround	5	5	TAPE 5	5

Originale		Sostituto	
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
TUN-M	Tun-M/[≡+]	APP REPEAT	Green / APP / Repeat
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEM	Mem/[≡♦]	REC MODE	Rec / Rec Mode
TUNING ▲	Tuning ▲	TUNE+	>> / Tune+
DIRECT	Direct	PROGRAM TV/RADIO	TV/Radio /
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PRESET ▲	Preset ▲	PRESET+	>>I / Preset+
TUNING▼	Tuning▼	TUNE-	<< / Tune-
OSD	OSD	MEDIA DISPLAY	Display / Media
D.SKIP RDS	RDS	RDS AV INPUT	AV / Input / RDS
PRESET ▼	Preset ▼	PRESET-	I<< / Preset-
DOLBY	Dolby	TITLE SOUND	Sound / Title
DTS SURR	DTS Surr.	LIST SMART	Smart / List

Originale		Sostituto	
DTS NEO:6	DTS Neo 6	EQ SUBTITLE	Subtitle / EQ
LOGIC 7	Logic 7	Prime Video RANDOM	Blue / Prime Video / Random
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
DWN SKIP	I<</Skip Down	SHIFT + PRESET-	Shift + I<< / Preset-
SKIP UP	Skip Up/>>I	SHIFT + PRESET+	Shift + >>I / Preset+
<< DVD	<< DVD	SHIFT + TUNE-	Shift + << /
Play DVD	Play DVD	SLOW	Play / Slow
>> DVD	>> DVD	SHIFT + TUNE+	Shift + >> /
Stop DVD	Stop DVD	HOLD	Stop / Hold
Pause DVD	Pause DVD	STEP-FREEZE	Pause / Step / Freeze

Originale		Sostituto	
	Power On		Power
	Power Off	SHIFT +	Shift + Power
VOL.	Vol +	VOL +	Vol +
NIGHT	Night	ANGLE INFO	Info / Angle
M-ROOM	M-Room	SIZE ZOOM	Zoom / Size
VOL.	Vol -	VOL −	Vol -
CH.	CH. / [≡?]	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Up		Up
MENU SPKR	SPKR/Menu	HOME MENU	Menu / Home
	Left		Left
SET	Set	TOP MENU D.MENU	D.Menu / Top
	Right		Right
DIGITAL	Digital / [≡X]	NETFLIX SEARCH	Red / Netflix / Search
	Down		Down
DELAY NORMAL	Delay/Normal	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2

Originale		Sostituto	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
TUN-M	Tun-M/ [≡+]	APP REPEAT	Green / APP / Repeat
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEM	Mem/ [≡♦]	REC MODE	Rec / Rec Mode
DIRECT	Direct	PROGRAM TV/RADIO	TV/Radio /
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PRESET	Preset ▲	SHIFT + PRESET+	Shift + >>I / Preset+
D.SKIP RDS	RDS/D.Skip	RDS AV INPUT	AV / Input / RDS
PRESET	Preset ▼	SHIFT + PRESET-	Shift + I<< / Preset-
DWN SKIP	I<<	PRESET-	I<< / Preset-
SKIP UP	>>I	PRESET+	>>I / Preset+

Originale		Sostituto	
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze

Originale	Sostituto

Originale		Sostituto	
POWER ON	Power On		Power
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MEM	Mem/[≡♦]	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
DWN SKIP	I <<	PRESET-	I << / Preset-
SKIP UP	>>I	PRESET+	>>I / Preset+
DIRECT	Direct	PROGRAM TV/RADIO	TV/Radio /
DELAY NORMAL	Delay/Normal	OPT-TOOLS SETUP	Setup / OPT /
D.SKIP RDS	RDS/D.Skip	RDS AV INPUT	AV / Input / RDS
MENU SPKR	SPKR/Menu	HOME MENU	Menu / Home
POWER ON	Power (On/Off)	OK	OK
CLEAR	Clear VCR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Vol + VCR	VOL +	Vol +
	PR+ VCR	CH PAGE +	CH+ / Page+

Originale		Sostituto	
	Vol - VCR	VOL −	Vol -
	PR- VCR	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
TUN-M	Tun-M/[≡+]	APP REPEAT	Green / APP / Repeat
PRESET ▲	Preset ▲/Blue	Prime Video RANDOM	Blue / Prime Video / Random
POWER OFF	Power Off	SHIFT +	Shift + Power
	Play VCR	SHIFT + SLOW	Shift + Play /
	Stop VCR	SHIFT + HOLD	Shift + Stop / Hold

Originale	Sostituto	Originale	Sostituto
Rec VCR	SHIFT + REC MODE		
<< VCR	SHIFT + TUNE-		
>> VCR	SHIFT + TUNE+		
1 VCR	SHIFT + TV 1		
2 VCR	SHIFT + DVD 2		
3 VCR	SHIFT + CD - STB 3		
4 VCR	SHIFT + VIDEO 4		
5 VCR	SHIFT + TAPE 5		
6 VCR	SHIFT + TUNER 6		
7 VCR	SHIFT + AUX - HDD 7		
8 VCR	SHIFT + USB 8		
9 VCR	SHIFT + BLUETOOTH 9		
0 VCR	SHIFT + HDMI - SAT 0		

Originale	Sostituto	Originale	Sostituto
<>	SLOW Pl ay / Sl ow		
>>	TUNE+ >> / Tune+		
<<	TUNE- << / Tune-		
St op	HOLD St op / Hol d		
Rec	REC MODE Rec / Rec Mode		