| Originale | | Sostituto | |
|---|---|---|---|
| | Power | | Power |
| INPUT | Input | TIMER AV | AV |
| P.Mode | P. Mode | SHIFT + PICTURE FORMAT | Shift + Format |
| P.Size | P. Size | PICTURE FORMAT | Format |
| S.Mode | S. Mode | SHIFT + SOUND DUAL | Shift + Dual |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| GUIDE | Guide | -/-- GUIDE | Guide |

| Originale | | Sostituto | |
|---|---|---|---|
| INFO | Info | DISPLAY INFO | Info |
| CH.List | CH. List | DISC NAV LIST | List |
| | Mute | MUTE | Mute |
| | Home | HOME SMART | Smart |
| VOL | Vol + | + VOL | Vol + |
| VOL | Vol - | VOL − | Vol - |
| CH | CH+ | + CH | Ch + |
| CH | CH- | CH − | Ch - |
| | ☼ | TOP MENU MENU | Menu |
| | [ ≡] | SETTINGS OPT | Options |
| BACK | Back | RETURN BACK | Back |
| EXIT | Exit | CLEAR EXIT | Exit |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | Ok |

| Originale | | Sostituto | | Originale | Sostituto |
|---|---|---|---|---|---|
| A | Red | A | Red | | |
| B | Green | B | Green | | |
| C | Yellow | C | Yellow | | |
| D | Blue | D | Blue | | |
| << | << | << | << | | |
| >> | >> | >> | >> | | |
| ▶ | Play | PLAY MODE ▶ | Play | | |
| ■ | Stop | ■ | Stop | | |
| II | Pause | II | Pause | | |
| ● | Rec | REC MODE ● | Rec | | |
| Subtitle | Subtitle | AD SUBT | Subt | | |
| Language | Language | SOUND DUAL | Dual | | |
| DMP | DMP | SEARCH TV/R | TV/R | | |
| TXT | TXT | REPEAT TEXT | Text | | |
| YouTube | YouTube | APP MEDIA | Media | | |
| NETFLIX | Netflix | SHIFT + APP MEDIA | Shift + Media | | |
| wuaki.tv | Wuaki.Tv | ECO 3D | 3D | | |