Mandis shop

Philips REMCON1664

Originale	Sostituto	Originale	Sostituto
Eject	Eject / Surround	Record/OTR	Rec / Rec Mode
Standby/On	Power	Up	Up
Menu	Menu / Home	Play	Play / Slow
Status/Exit	Exit / Cancel / Clear	>I <I/ Still	Pause / Step / Freeze
Clear	Shift + Exit / Cancel / Clear	<<	<< / Tune-
1	1	Left	Left
2	2	Right	Right
3	3	>>	>> / Tune+
4	4	P+	CH+ / Page+
5	5	Stop	Stop / Hold
6	6	Down	Down
7	7	Vol +	Vol +
8	8	P-	CH- / Page-
9	9	Mute	Mute / Dimmer
Sleep	Sleep / Timer	Vol -	Vol -
0	0	Red/SV/V+	Red / Netflix / Search
System	Smart / List	Green/Smart Picture	Green / APP / Repeat

Originale	Sostituto	Originale	Sostituto
Green/Smart	Picture / Format		
Yellow	Yellow / YouTube / Repeat		
Blue/Index	Blue / Prime Video / Random		
[=i]	Info / Angle		
Text	Text / Goto		
[=?]	D.Menu / Top		
[=♦]	Zoom / Size		
[=x]	TV/Radio /		
[=o]	Setup / OPT /		
[=+]	AV / Input / RDS		