Originale		Sostituto	
POWER	Power		Power
RADIO&INPUT	Radio/Input	SEARCH TV/R	TV/R
OPEN/CLOSE	Open/Close	ZOOM	Eject
MARKER	Marker	AD SUBT	Subt
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
INFO/DISPLAY	Info/Display	DISPLAY INFO	Info
HOME	Home	HOME SMART	Smart
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
BACK	Back	RETURN BACK	Back
TITLE/POPUP	Title/Popup	-/-- GUIDE	Guide
PRESET +	Up/Preset+		Up
PRESET -	Down/Preset-		Down
	Right/Tuning+		Right
	Left/Tuning-		Left
ENTER	Enter	OK	Ok
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play

Originale		Sostituto	
PAUSE/STEP	Pause/Step		Pause
SKIP	I<< Skip		I<<
SCAN	<< Scan		<<
SCAN	Scan >>		>>
SKIP	Skip >>I		>>I
SPEAKER LEVEL	Speaker Level	APP MEDIA	Media
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
OPTICAL	Optical	SETTINGS OPT	Options
RDS R	Red/RDS	A	Red
PTY G	Green/PTY	B	Green
PTY SEARCH	Yellow/PTY Search	C	Yellow
MONO/STEREO B	Blue/Mono Stereo	D	Blue
1	1	1	1
ABC 2	2	2	2

Originale		Sostituto	
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
CLEAR	Cl ear	CLEAR EXIT	Exi t
REPEAT	Repeat	REPEAT TEXT	Text
SLEEP	Sl eep	PROG SLEEP	Sl eep
REC	Rec	REC MODE	Rec
*	*	ECO 3D	3D
*	*	TIMER AV	AV
POWER	Power Tv	SHIFT + Power	Shi f t + Power
AV/INPUT	AV/ I nput Tv	SHIFT + TIMER AV	Shi f t + AV
PR/CH	PR/ CH+ Tv	CH +	Ch +

Originale		Sostituto	
PR/CH	PR/ CH- Tv	CH -	Ch -
VOL +	Vol + Tv	SHIFT + VOL +	Shi f t + Vol +
VOL -	Vol - Tv	SHIFT + VOL -	Shi f t + Vol -
MUTE	Mut e Tv	SHIFT + MUTE	Shi f t + Mut e