Originale		Sostituto	
	Power		Power
TV/RAD	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
SUBTITLE Q.MENU	Q.Menu/Subtitle	HOME MENU	Menu / Home
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
AD	AD	LANG I/II AUDIO	Audio / Lang I/II
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	SHIFT + LIST SMART	Shift + Smart / List
0	0	HDMI-SAT 0	0

Originale		Sostituto	
Q.VIEW	Q.View	TOP MENU D.MENU	D.Menu / Top
	Vol +	+ VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P PAGE	P+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
INFO	Info	ANGLE INFO	Info / Angle
P PAGE	P-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
SMART	Smart	LIST SMART	Smart / List
MY APPS	My APPS	MEDIA DISPLAY	Display / Media
TEXT	Text	GOTO TEXT	Text / Goto
	Up		Up
T.OPT	T.Opt	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Left		Left
OK	OK	OK	OK
	Right		Right

Originale	Sostituto	Originale	Sostituto
Back	Back / Return		
Down	Down		
Exit	Exit / Cancel / Clear		
APP/*	SHIFT + APP (REPEAT) Shift + Green / APP /		
Rec/*	REC MODE Rec / Rec Mode		
Stop/Line Tv	HOLD Stop / Hold		
<<	TUNE- << / Tune-		
Play	SLOW Play / Slow		
Pause	STEP-FREEZE Pause / Step / Freeze		
>>	TUNE+ >> / Tune+		
Red	NETFLIX (SEARCH) Red / Netflix / Search		
Green	APP (REPEAT) Green / APP / Repeat		
Yellow	YouTube (REPEAT A-B) Yellow / YouTube / Repeat		
Blue	Prime Video (RANDOM) Blue / Prime Video / Random		