Originale	Sostituto		Originale	Sostituto	
Power		Power	Vol +		Vol +
Mute		Mute / Dimmer	Network		Smart / List
Play/Pause		Play / Slow	CH+		CH+ / Page+
I <<</Tune-		<< / Tune-	Vol -		Vol -
>>I / Tune+		>> / Tune+	Media Player		Display / Media
I <<</Tune-		I << / Preset-	CH-		CH- / Page-
>>I / Tune+		>>I / Preset+	Tv Audio		1
Sleep		Sleep / Timer	DVD		2
Setup		Setup / OPT /	CD		3
Option		Menu / Home	Blu-Ray		4
Up		Up	M-XPort		5
Info		Info / Angle	Tuner		6
Left		Left	AUX 1		7
Enter		OK	iPod/USB		8
Right		Right	Internet Radio		9
Down		Down	AUX 2		Guide / EPG / -/--
Back		Back / Return	CBL/SAT		0

Originale	Sostituto	Originale	Sostituto
Game	PC FAV MARKER Fav / Marker / PC		
Red/Movie	NETFLIX SEARCH Red / Netflix / Search		
Green/Music	APP REPEAT Green / APP / Repeat		
Yellow/Pure	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue/Game	Prime Video RANDOM Blue / Prime Video / Random		
Favorite Station 1	SHIFT + TV 1 Shift + 1		
Favorite Station 2	SHIFT + DVD 2 Shift + 2		
Favorite Station 3	SHIFT + CD - STB 3 Shift + 3		

Originale	Sostituto		Originale	Sostituto	
Power		Power	Vol -		Vol -
Mute		Mute / Dimmer	Media Player		Display / Media
Play/Pause		Play / Slow	CH-		CH- / Page-
I <<</Tune-		<< / Tune-	Tv Audio		1
>>I / Tune+		>> / Tune+	DVD		2
I <<</Tune-		I << / Preset-	CD		3
>>I / Tune+		>>I / Preset+	Blu-Ray		4
Sleep		Sleep / Timer	M-XPort		5
Up		Up	Tuner		6
Left		Left	AUX 1		7
Enter		OK	iPod/USB		8
Right		Right	Internet Radio		9
Down		Down	AUX 2		Guide / EPG / -/--
Back		Back / Return	CBL/SAT		0
Vol +		Vol +	Game		Fav / Marker / PC
Network		Smart / List	Favorite Station 1		Shift + 1
CH+		CH+ / Page+	Favorite Station 2		Shift + 2

Originale	Sostituto	Originale	Sostituto
Favorite Station 3	SHIFT + CD-STB 3		