Originale	Sostituto	Originale	Sostituto
Power Receiver	Power	2 Receiver	2
Enter Receiver	Ok	3 Receiver	3
Up Receiver	Up	4 Receiver	4
Down Receiver	Down	5 Receiver	5
Right Receiver	Right	6 Receiver	6
Left Receiver	Left	7 Receiver	7
Return Receiver	Back	8 Receiver	8
Q/Setup Receiver	Smart	9 Receiver	9
Home/Audio	Media	0/11 Receiver	0
Play Receiver	Play	+10/--/--10/Dimmer/D.Tun Receiver	Shift + Guide
I<< Receiver	I<<	CLR/Sleep/12 Receiver	Pre Ch
>>I Receiver	>>I	Movie Tv/Red/Search	Red
<< Receiver	<<	Music/Green/Repeat Receiver	Green
>> Receiver	>>	Game/Yellow/Random Receiver	Yellow
Pause Receiver	Pause	Stereo/Blue/Mode Receiver	Blue
Stop Receiver	Stop	Vol + Receiver	Vol +
1 Receiver	1	Vol - Receiver	Vol -

Originale	Sostituto	Originale	Sostituto
CH Disc/Album+ Receiver	Ch +	Yellow Tv	Subt
CH Disc/Album- Receiver	Ch -	Blue Tv	TV/R
Power Tv	Shift + Power	1 Tv	Shift + 1
Input Tv	AV	2 Tv	Shift + 2
CH+ Tv	Shift + Ch +	3 Tv	Shift + 3
CH- Tv	Shift + Ch -	4 Tv	Shift + 4
Up Tv	Shift + Up	5 Tv	Shift + 5
Enter Tv	Shift + Ok	6 Tv	Shift + 6
Down Tv	Shift + Down	7 Tv	Shift + 7
Right Tv	Shift + Right	8 Tv	Shift + 8
Left Tv	Shift + Left	9 Tv	Shift + 9
Menu/Prev CH	Menu	0/11 Tv	Shift + 0
Top Menu/Guide	Shift + Menu	+10/--/--10 Tv	Guide
Return Tv	Shift + Back	CLR/Sleep/12	Shift + Pre Ch
Q/Setup Tv	Shift + Smart	Vol + Tv	Shift + Dual
Red Tv	Options	Vol - Tv	Shift + Options
Green Tv	Dual	AUX	Text

Originale		Sostituto		Originale	Sostituto
TV/CD	TV/ CD	PICTURE FORMAT	Format		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT + AD SUBT	Shift + Subt		
NET	NET	SHIFT + APP MEDIA	Shift + Media		
PC	PC	SHIFT + SEARCH TV/R	Shift + TV/ R		
BD/DVD	BD/ DVD	SHIFT + REPEAT TEXT	Shift + Text		
USB	USB	SHIFT + TIMER AV	Shift + AV		

Originale	Sostituto	Originale	Sostituto
Power BD/DVD	Power	Stop BD/DVD	Stop
Menu/Prev CH	Menu	Movie Tv/Red/Search	Red
Top Menu/Guide BD/DVD	Options	Music/Green/Repeat BD/DVD	Green
Q/Setup	Smart	Game/Yellow/Random BD/DVD	Yellow
Return BD/DVD	Back	Stereo/Blue/Mode BD/DVD	Blue
Home/Audio	Media	1 BD/DVD	1
Enter BD/DVD	Ok	2 BD/DVD	2
Up BD/DVD	Up	3 BD/DVD	3
Down BD/DVD	Down	4 BD/DVD	4
Right BD/DVD	Right	5 BD/DVD	5
Left BD/DVD	Left	6 BD/DVD	6
I << BD/DVD	I <<	7 BD/DVD	7
>>I BD/DVD	>>I	8 BD/DVD	8
<< BD/DVD	<<	9 BD/DVD	9
>> BD/DVD	>>	0/11 BD/DVD	0
Play BD/DVD	Play	+10/--/--10/D.Tun Dimmer BD/DVD	Guide
Pause BD/DVD	Pause	CLR/Sleep/12	Pre Ch

BD/DVD

Originale	Sostituto
CBL/ SAT	Text
Vol + Receiver	Vol +
Vol - Receiver	Vol -
Power CBL/ SAT	Shift + Power
CH Disc/ Album+ CBL/ SAT	Ch +
CH Disc/ Album- CBL/ SAT	Ch -
Menu/ Prev CH CBL/ SAT	Shift + Menu
Top Menu/ Guide CBL/ SAT	Shift + Options
Return CBL/ SAT	Shift + Back
Q/ Setup	Shift + Smart
Up CBL/ SAT	Shift + Up
Enter CBL/ SAT	Shift + Ok
Down CBL/ SAT	Shift + Down
Right CBL/ SAT	Shift + Right
Left CBL/ SAT	Shift + Left
Pause CBL/ SAT	Shift + Pause
Stop CBL/ SAT	Shift + Stop

Originale	Sostituto
<< CBL/ SAT	Shift + Ch -
>> CBL/ SAT	Shift + Ch +
Play CBL/ SAT	3D
Movie Tv/ Red/ Search	Dual
Music/ Green/ Repeat CBL/ SAT	Subt
Game/ Yellow/ Random CBL/ SAT	AV
Stereo/ Blue/ Mode CBL/ SAT	Format
1 CBL/ SAT	Shift + 1
2 CBL/ SAT	Shift + 2
3 CBL/ SAT	Shift + 3
4 CBL/ SAT	Shift + 4
5 CBL/ SAT	Shift + 5
6 CBL/ SAT	Shift + 6
7 CBL/ SAT	Shift + 7
8 CBL/ SAT	Shift + 8
9 CBL/ SAT	Shift + 9
0/ 11 CBL/ SAT	Shift + 0

Originale	Sostituto	Originale	Sostituto
BD/DVD BD/ DVD	SEARCH TV/R TV/ R		

Originale	Sostituto
Power TV/ CD	Power
CH/ Disc+ TV/ CD	Ch +
CH/ Disc TV/ CD	Ch -
Return TV/ CD	Back
Q/ Setup TV/ CD	Smart
Home/ Audio	Media
Up TV/ CD	Up
Down TV/ CD	Down
Right TV/ CD	Right
Left TV/ CD	Left
Enter TV/ CD	Ok
I << TV/ CD	I <<
>>I TV/ CD	>>I
<< TV/ CD	<<
>> TV/ CD	>>
Play TV/ CD	Play
Pause TV/ CD	Pause

Originale	Sostituto
Stop TV/ CD	Stop
Movie Tv/ Red/ Search	Red
Music/ Green/ Repeat TV/ CD	Green
Game/ Yellow/ Random TV/ CD	Yellow
Stereo/ Blue/ Mode TV/ CD	Blue
1 TV/ CD	1
2 TV/ CD	2
3 TV/ CD	3
4 TV/ CD	4
5 TV/ CD	5
6 TV/ CD	6
7 TV/ CD	7
8 TV/ CD	8
9 TV/ CD	9
0/ 11 TV/ CD	0
+10/ - - / - - 10/ D. Tun Dimmer TV/ CD	Guide
CLR/ Sleep/ 12	Pre Ch

TV/ CD

Originale		Sostituto	
VOL ▲	Vol + Recei ver	+ VOL	Vol +
VOL ▼	Vol - Recei ver	VOL –	Vol -
TV/CD	TV/ CD	SEARCH TV/R	TV/ R

Originale	Sostituto

Originale	Sostituto
Power Receiver Zone 2	Power
Vol + Zone 2	Vol +
Vol - Zone 2	Vol -
CH Disc/Album+ Zone 2	Ch +
CH Disc/Album- Zone 2	Ch -
Up Zone 2	Up
Enter Zone 2	Ok
Down Zone 2	Down
Right Zone 2	Right
Left Zone 2	Left
Return Zone 2	Back
Q/Setup Zone 2	Smart
Home/Audio Zone	Media
I << Zone 2	I <<
>>I Zone 2	>>I
Play Zone 2	Play
>> Zone 2	>>

Originale	Sostituto
<< Zone 2	<<
Pause Zone 2	Pause
Stop Zone 2	Stop
Movie Tv/Red/Search	Red
Music/Green/Repeat Zone 2	Green
Game/Yellow/Random Zone 2	Yellow
Stereo/Blue/Mode Zone 2	Blue
1 Zone 2	1
2 Zone 2	2
3 Zone 2	3
4 Zone 2	4
5 Zone 2	5
6 Zone 2	6
7 Zone 2	7
8 Zone 2	8
9 Zone 2	9
0/11 Zone 2	0

Originale	Sostituto	Originale	Sostituto
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	GUIDE Gui de		
CLR/ Sl eep/ 12	PRE-CH Pr e Ch		