| Originale | | Sostituto | |
|---|---|---|---|
| ON/STANDBY | Power | | Power |
| DISPLAY | Display | DISPLAY INFO | Info |
| DVD/BD | DVD / BD | SHIFT + 1 | Shift + 1 |
| VCR/DVR | VCR / DVR | SHIFT + 2 | Shift + 2 |
| CBL/SAT | CBL/SAT | SHIFT + 3 | Shift + 3 |
| CD | CD | SHIFT + 4 | Shift + 4 |
| AUX | AUX | SHIFT + 5 | Shift + 5 |
| TV/TAPE | TV / TAPE | SHIFT + 6 | Shift + 6 |
| TUNER | TUNER | SHIFT + 7 | Shift + 7 |
| PORT | PORT | SHIFT + 8 | Shift + 8 |
| MUTING | Muting | MUTE | Mute |
| CH DISC | CH/Disc/Album | + CH | Ch + |
| ALBUM | CH/Disc/Album | CH − | Ch - |
| VOL | Vol + | + VOL | Vol + |
| VOL | Vol - | VOL − | Vol - |
| | Up | | Up |
| PLAYLIST /CATEGORY | Left | | Left |

| Originale | | Sostituto | |
|---|---|---|---|
| ENTER | Enter | OK | Ok |
| PLAYLIST /CATEGORY | Right | | Right |
| | Down | | Down |
| SETUP | Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| AUDIO | Audio | SOUND DUAL | Dual |
| | I<< | | I<< |
| | >>I | | >>I |
| | << | | << |
| | Play | PLAY MODE | Play |
| | >> | | >> |
| | Pause | | Pause |
| | Stop | | Stop |
| MOVIE/TV SEARCH | Movie | A | Red |
| LISTEN MUSIC REPEAT | Music/Repeat | B | Green |
| G MODE GAME RANDOM | Game/Random | C | Yellow |
| STEREO PLAY MODE | Stereo/Play Mode | D | Blue |

| Originale | | Sostituto | | Originale | Sostituto |
|---|---|---|---|---|---|
| 1 | 1 | 1 | 1 | | |
| 2 | 2 | 2 | 2 | | |
| 3 | 3 | 3 | 3 | | |
| 4 | 4 | 4 | 4 | | |
| 5 | 5 | 5 | 5 | | |
| 6 | 6 | 6 | 6 | | |
| 7 | 7 | 7 | 7 | | |
| 8 | 8 | 8 | 8 | | |
| 9 | 9 | 9 | 9 | | |
| 0 / 11 | 0/ 11 | 0 | 0 | | |
| +10 / - - / - - - 10/ Di m er / D. Tun | +10/ - - / - - - 10/ Di m er / D. Tun | GUIDE | Gui de | | |
| CLR / SLEEP / 12 | CLR/ Sl eep/ 12 | PRE-CH | Pr e Ch | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Originale | | Sostituto | |
|---|---|---|---|
| ON/STANDBY | Power BD/DVD | | Power |
| PREV CH/MENU | Menu/Prev CH | TOP MENU MENU | Menu |
| GUIDE/TOP MENU | Top Menu/Guide BD/DVD | SETTINGS OPT | Options |
| SETUP | Setup BD/DVD | HOME SMART | Smart |
| RETURN | Return BD/DVD | RETURN BACK | Back |
| AUDIO | Audio BD/DVD | APP MEDIA | Media |
| ENTER | Enter BD/DVD | OK | Ok |
| | Up BD/DVD | | Up |
| | Down BD/DVD | | Down |
| PLAYLIST /CATEGORY | Right BD/DVD | | Right |
| PLAYLIST /CATEGORY | Left BD/DVD | | Left |
| | I<< BD/DVD | | I<< |
| | >>I BD/DVD | | >>I |
| | << BD/DVD | | << |
| | >> BD/DVD | | >> |
| | Play BD/DVD | PLAY MODE | Play |
| | Pause/Play rev. BD/DVD | | Pause |

| Originale | | Sostituto | |
|---|---|---|---|
| | Stop BD/DVD | | Stop |
| MOVIE/TV SEARCH | Movie Tv/Search BD/DVD | A | Red |
| LISTENI MUSIC REPEAT | Music/Repeat | B | Green |
| G MODE GAME RANDOM | Game/Random | C | Yellow |
| STEREO PLAY MODE | Stereo/Play Mode BD/DVD | D | Blue |
| 1 | 1 BD/DVD | 1 | 1 |
| 2 | 2 BD/DVD | 2 | 2 |
| 3 | 3 BD/DVD | 3 | 3 |
| 4 | 4 BD/DVD | 4 | 4 |
| 5 | 5 BD/DVD | 5 | 5 |
| 6 | 6 BD/DVD | 6 | 6 |
| 7 | 7 BD/DVD | 7 | 7 |
| 8 | 8 BD/DVD | 8 | 8 |
| 9 | 9 BD/DVD | 9 | 9 |
| 11 0 | 0/11 BD/DVD | 0 | 0 |
| 10 +10 D.TUN DIMMER | +10/--/--10/D.Tu Dimmer BD/DVD | -/-- GUIDE | Guide |
| 12 CLR SLEEP | CLR/Sleep/12 | FAV PRE-CH | Pre Ch |

BD/DVD

| Originale | | Sostituto | |
|---|---|---|---|
| CBL/SAT | CBL/SAT | REPEAT TEXT | Text |
| MUTING | Muting Receiver | MUTE | Mute |
| VOL | Vol + Receiver | + VOL | Vol + |
| VOL | Vol - Receiver | VOL − | Vol - |
| ON/STANDBY | Power CBL/SAT | SHIFT + | Shift + Power |
| CH DISC | CH Disc/Album+ CBL/SAT | + CH | Ch + |
| ALBUM | CH Disc/Album- CBL/SAT | CH − | Ch - |
| PREV CH/MENU | Menu/Prev CH CBL/SAT | SHIFT + TOP MENU MENU | Shift + Menu |
| GUIDE/TOP MENU | Top Menu/Guide CBL/SAT | SHIFT + SETTINGS OPT | Shift + Options |
| RETURN | Return CBL/SAT | SHIFT + RETURN BACK | Shift + Back |
| SETUP | Setup CBL/SAT | SHIFT + HOME SMART | Shift + Smart |
| | Up CBL/SAT | SHIFT + ▲ | Shift + Up |
| ENTER | Enter CBL/SAT | SHIFT + OK | Shift + Ok |
| | Down CBL/SAT | SHIFT + ▼ | Shift + Down |
| PLAYLIST /CATEGORY | Right CBL/SAT | SHIFT + ▶ | Shift + Right |
| PLAYLIST /CATEGORY | Left CBL/SAT | SHIFT + ◀ | Shift + Left |
| | Pause/Play rev. CBL/SAT | SHIFT + ❚❚ | Shift + Pause |

| Originale | | Sostituto | |
|---|---|---|---|
| | Stop CBL/SAT | SHIFT + ■ | Shift + Stop |
| | << CBL/SAT | SHIFT + CH − | Shift + Ch - |
| | >> CBL/SAT | SHIFT + + CH | Shift + Ch + |
| | Play CBL/SAT | ECO 3D | 3D |
| MOVIE/TV SEARCH | Movie Tv/Search CBL/SAT | SOUND DUAL | Dual |
| LISTENING MUSIC REPEAT | Music/Repeat CBL/SAT | AD SUBT | Subt |
| G MODE GAME RANDOM | Game/Random | TIMER AV | AV |
| STEREO PLAY MODE | Stereo/Play Mode CBL/SAT | PICTURE FORMAT | Format |
| 1 | 1 CBL/SAT | SHIFT + 1 | Shift + 1 |
| 2 | 2 CBL/SAT | SHIFT + 2 | Shift + 2 |
| 3 | 3 CBL/SAT | SHIFT + 3 | Shift + 3 |
| 4 | 4 CBL/SAT | SHIFT + 4 | Shift + 4 |
| 5 | 5 CBL/SAT | SHIFT + 5 | Shift + 5 |
| 6 | 6 CBL/SAT | SHIFT + 6 | Shift + 6 |
| 7 | 7 CBL/SAT | SHIFT + 7 | Shift + 7 |
| 8 | 8 CBL/SAT | SHIFT + 8 | Shift + 8 |
| 9 | 9 CBL/SAT | SHIFT + 9 | Shift + 9 |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| 0/ 11 CBL/ SAT | SHIFT + 0 Shift + 0 | | |
| DVD/ BD | SEARCH TV/R TV/ R | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|---|---|---|---|
| ON/STANDBY | Power CD | | Power |
| CH DISC | CH/Disc+ CD | CH + | Ch + |
| ALBUM | CH/Disc- CD | CH − | Ch - |
| RETURN | Return CD | RETURN BACK | Back |
| SETUP | Setup CD | HOME SMART | Smart |
| AUDIO | Audio CD | APP MEDIA | Media |
| | Up CD | | Up |
| | Down CD | | Down |
| PLAYLIST /CATEGORY | Right CD | | Right |
| PLAYLIST /CATEGORY | Left CD | | Left |
| ENTER | Enter CD | OK | Ok |
| | I<< CD | | I<< |
| | >>I CD | | >>I |
| | << CD | | << |
| | >> CD | | >> |
| | Play CD | PLAY MODE | Play |
| | Pause CD | | Pause |

| Originale | | Sostituto | |
|---|---|---|---|
| | Stop CD | | Stop |
| MOVIE/TV SEARCH | Movie Tv/Search | A | Red |
| LISTENI MUSIC REPEAT | Music/Repeat | B | Green |
| G MODE GAME RANDOM | Game/Random | C | Yellow |
| STEREO PLAY MODE | Stereo/Play Mode | D | Blue |
| 1 | 1 CD | 1 | 1 |
| 2 | 2 CD | 2 | 2 |
| 3 | 3 CD | 3 | 3 |
| 4 | 4 CD | 4 | 4 |
| 5 | 5 CD | 5 | 5 |
| 6 | 6 CD | 6 | 6 |
| 7 | 7 CD | 7 | 7 |
| 8 | 8 CD | 8 | 8 |
| 9 | 9 CD | 9 | 9 |
| 11 0 | 0/11 CD | 0 | 0 |
| -/--10 +10 D.TUN DIMMER | +10/--/--10/D.Tu Dimmer CD | -/-- GUIDE | Guide |
| 12 CLR SLEEP | CLR/Sleep/12 | FAV PRE-CH | Pre Ch |

CD

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| MUTING Muting Receiver | MUTE Mute | | |
| VOL + Vol + Receiver | + VOL Vol + | | |
| VOL - Vol - Receiver | VOL – Vol - | | |
| CD CD | SEARCH TV/R TV/R | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|---|---|---|---|
| ON/STANDBY | Power Receiver Zone 2 | | Power |
| MUTING | Muting Receiver | MUTE | Mute |
| VOL | Vol + Zone 2 | + VOL | Vol + |
| VOL | Vol - Zone 2 | VOL − | Vol - |
| CH DISC | CH Disc/Album+ Zone 2 | + CH | Ch + |
| ALBUM | CH Disc/Album- Zone 2 | CH − | Ch - |
| | Up Zone 2 | | Up |
| ENTER | Enter Zone 2 | OK | Ok |
| | Down Zone 2 | | Down |
| PLAYLIST /CATEGORY | Right Zone 2 | | Right |
| PLAYLIST /CATEGORY | Left Zone 2 | | Left |
| RETURN | Return Zone 2 | RETURN BACK | Back |
| SETUP | Setup Zone 2 | HOME SMART | Smart |
| AUDIO | Audio Zone 2 | APP MEDIA | Media |
| | I<< Zone 2 | | I<< |
| | >>I Zone 2 | | >>I |
| | Play Zone 2 | PLAY MODE | Play |

| Originale | | Sostituto | |
|---|---|---|---|
| | >> Zone 2 | | >> |
| | << Zone 2 | | << |
| | Pause Zone 2 | | Pause |
| | Stop Zone 2 | | Stop |
| MOVIE/TV SEARCH | Movie Tv/Search Zone 2 | A | Red |
| LISTENI MUSIC REPEAT | Music/Repeat | B | Green |
| G MODE GAME RANDOM | Game/Random | C | Yellow |
| STEREO PLAY MODE | Stereo/Play Mode Zone 2 | D | Blue |
| 1 | 1 Zone 2 | 1 | 1 |
| 2 | 2 Zone 2 | 2 | 2 |
| 3 | 3 Zone 2 | 3 | 3 |
| 4 | 4 Zone 2 | 4 | 4 |
| 5 | 5 Zone 2 | 5 | 5 |
| 6 | 6 Zone 2 | 6 | 6 |
| 7 | 7 Zone 2 | 7 | 7 |
| 8 | 8 Zone 2 | 8 | 8 |
| 9 | 9 Zone 2 | 9 | 9 |

| Originale | | Sostituto | |
|---|---|---|---|
| 11 0 | 0/11 Zone 2 | 0 | 0 |
| 10 +10 D.TUN DIMMER | +10/--/--10/D.Tuner Dimmer Zone 2 | -/-- GUIDE | Guide |
| 12 CLR SLEEP | CLR/Sleep/12 | FAV PRE-CH | Pre Ch |

| Originale | Sostituto |
|---|---|
| | |
| | |
| | |