Originale	Sostituto	Originale	Sostituto
RCVR Sleep	Sleep / Timer	RCVR Muting	Mute / Dimmer
RCVR On	Power	RCVR Level	Shift + Down
RCVR Standby	Shift + Power	RCVR Level Up	Shift + Up
RCVR Return	Back / Return	RCVR I<<	I<< / Preset-
RCVR Setup	Setup / OPT /	RCVR Play	Play / Slow
RCVR Disc+	CH+ / Page+	RCVR >>I	>>I / Preset+
RCVR Up	Up	RCVR <<	<< / Tune-
RCVR Vol +	Vol +	RCVR Stop	Stop / Hold
RCVR Disc-	CH- / Page-	RCVR >>	>> / Tune+
RCVR Left	Left	RCVR Rec /	Blue / Prime Video / Random
RCVR Enter	OK	RCVR Pause / Play Rev.	Pause / Step / Freeze
RCVR Right	Right	Open / Close	Eject / Surround
RCVR Vol -	Vol -	RCVR Input Sel.	2
RCVR Down	Down	RCVR Input Sel.	3
RCVR Audio	Audio / Lang I/II	RCVR Input Sel.	4
RCVR CH Sel / Top Menu	D. Menu / Top	RCVR Input Sel.	1
RCVR Test / Menu	Menu / Home	RCVR Input Sel.	5

TAP

Originale		Sostituto	
TUN	RCVR Input Sel.	TUNER 6	6
V3	RCVR Input Sel.	AUX - HDD 7	7
V4	RCVR Input Sel.	USB 8	8
V5	RCVR Input Sel.	BLUETOOTH 9	9
PH	RCVR Input Sel.	HDMI - SAT 0	0
1 STEREO	RCVR Stereo	SHIFT + TV 1	Shift + 1
2 DIRECT	RCVR Direct	SHIFT + DVD 2	Shift + 2
3 DSP ►	RCVR DSP ►	SHIFT + CD - STB 3	Shift + 3
4 SURR	RCVR SURR	SHIFT + VIDEO 4	Shift + 4
4 SURR	RCVR SURR	SHIFT + SURROUND ⏏	Shift + Eject / Surround
5 THX	RCVR THX	SHIFT + TAPE 5	Shift + 5
6 DSP ◄	RCVR ◄ DSP	SHIFT + TUNER 6	Shift + 6
7 SP A	RCVR SP A	SHIFT + AUX - HDD 7	Shift + 7
8 SP B	RCVR SP B	SHIFT + USB 8	Shift + 8
9 Re-EQ	RCVR Re-EQ	EQ SUBTITLE	Subtitle / EQ
9 Re-EQ	RCVR Re-EQ	SHIFT + BLUETOOTH 9	Shift + 9
+10 DISPLAY	RCVR Display	MEDIA DISPLAY	Display / Media

Originale		Sostituto	
0 DIMMER	RCVR Dimmer	SHIFT + HDMI - SAT 0	Shift + 0
0 DIMMER	RCVR Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SEARCH ZONE 2 ENTER	RCVR Zone 2	LIST SMART	Smart / List

Originale		Sostituto	
	ON		Power
	STDBY	SHIFT +	Shift + Power
	Return	RETURN BACK	Back / Return
	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Disc+	CH PAGE +	CH+ / Page+
	Up		Up
	Vol +	VOL +	Vol +
	Disc-	CH PAGE −	CH- / Page-
	Left		Left
	Enter	OK	OK
	Right		Right
	Vol -	VOL −	Vol -
	Down		Down
	Top Menu	TOP MENU D.MENU	D. Menu / Top
	Menu	HOME MENU	Menu / Home
	Muting	DIMMER MUTE	Mute / Dimmer
	Angle	ANGLE INFO	Info / Angle

Originale		Sostituto	
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	>>	TUNE+	>> / Tune+
	Random	Prime Video RANDOM	Blue / Prime Video / Random
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Open / Close	SURROUND	Eject / Surround
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7

Originale		Sostituto	
8 SP B	8	USB 8	8
9 Re-EQ	9	BLUETOOTH 9	9
+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0	HDMI - SAT 0	0
SEARCH ZONE 2 ENTER	Search	NETFLIX SEARCH	Red / Netflix / Search

Originale	Sostituto

Originale		Sostituto		Originale		Sostituto	
ON	ON	Power	Power	3	3	3	3
STDBY	STDBY	SHIFT + Power	Shift + Power	4	4	4	4
Disc+	CH DISC	CH PAGE	CH+ / Page+	5	5	5	5
Vol +	VOL	VOL	Vol +	6	6	6	6
Vol -	VOL	VOL	Vol -	7	7	7	7
Muting	MUTING	DIMMER MUTE	Mute / Dimmer	8	8	8	8
I<<		PRESET-	I<< / Preset-	9	9	9	9
Play		SLOW	Play / Slow	+10	+10	GUIDE EPG	Guide / EPG / -/--
>>I		PRESET+	>>I / Preset+	0	0	0	0
<<		TUNE-	<< / Tune-				
Stop		HOLD	Stop / Hold				
>>		TUNE+	>> / Tune+				
Random	RANDOM	Prime Video RANDOM	Blue / Prime Video / Random				
Pause		STEP-FREEZE	Pause / Step / Freeze				
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround				
1	STEREO	TV 1	1				
2	DIRECT	DVD 2	2				

Originale		Sostituto		Originale		Sostituto	
ON	ON	Power		1 STEREO	1	TV 1	1
STDBY	STDBY	SHIFT +	Shift + Power	2 DIRECT	2	DVD 2	2
VOL	Vol +	VOL +	Vol +	3 DSP	3	CD-STB 3	3
ENTER	Enter	OK	OK	4 SURR	4	VIDEO 4	4
ENTER	Enter	PC FAV MARKER	Fav / Marker / PC	5 THX	5	TAPE 5	5
VOL	Vol -	VOL −	Vol -	6 DSP	6	TUNER 6	6
MUTING M	Muting	DIMMER MUTE	Mute / Dimmer	7 SP A	7	AUX-HDD 7	7
I<<	I<<	PRESET- I<<	I<< / Preset-	8 SP B	8	USB 8	8
Play	Play	SLOW	Play / Slow	9 Re-EQ	9	BLUETOOTH 9	9
>>I	>>I	PRESET+ >>I	>>I / Preset+	+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--
<<	<<	TUNE- <<	<< / Tune-	0 DIMMER	0	HDMI-SAT 0	0
Stop	Stop	HOLD	Stop / Hold				
>>	>>	TUNE+ >>	>> / Tune+				
RANDOM R	Rec / Random	Prime Video RANDOM	Blue / Prime Video / Random				
RANDOM R	Rec / Random	REC MODE	Rec / Rec Mode				
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze				
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround				