Mandis shop

Optoma HD50

Originale		Sostituto	
ON	ON		Power
OFF	OFF	SHIFT +	Shift + Power
Pure Engine	PURE ENGINE	HOME SMART	Smart
Color Temp	COLOR TEMP	APP MEDIA	Media
Gamma	GAMMA	+ VOL	Vol +
CMS	CMS	VOL –	Vol -
Brightness	BRIGHTNESS	+ CH	Ch +
Depth 2D/3D	2D/3D DEPTH	ECO 3D	3D
Contrast	CONTRAST	CH –	Ch -
Mode	MODE	DISPLAY INFO	Info
3D Forma LR	3D FORMAT	PICTURE FORMAT	Format
Keystone +	UP /		Up
Keystone –	DOWN /		Down
Re-sync	RIGHT /		Right
Source	LEFT / SOURCE		Left
Source	LEFT / SOURCE	TIMER AV	AV
	OK	OK	Ok

Originale		Sostituto	
Menu	MENU	TOP MENU MENU	Menu
HDMI1	INPUT HDMI 1	1	1
HDMI2	INPUT HDMI 2	2	2
YPbPr	INPUT YPbPr	3	3
VGA	INPUT VGA	4	4
Video	INPUT VIDEO	5	5
4:3	FORMAT 4:3	A	Red
16:9	FORMAT 16:9	B	Green
LBX	FORMAT LBX	C	Yellow
Native	FORMAT NATIVE	D	Blue

https://redcontrols.it/Optoma/1620-974-telecomando-sostituzione-per-Optoma-HD50.htm