Mandis shop

Samsung AH5900004A

Originale	Sostituto	Originale	Sostituto
Power	Power	Vol +	Vol +
Timer On/Off	Guide / EPG / -/--	Vol -	Vol -
Mute	Mute / Dimmer	Down/I << CD	Down
EQ	Shift + Subtitle / EQ	Up/CD >>I	Up
Disc Skip	Eject / Surround	Tuning Mode	6
Program/Set	Menu / Home		
AUX	7		
Deck 1/2	Subtitle / EQ		
CD Repeat	Green / APP / Repeat		
Mo/St	Fav / Marker / PC		
Tuner/Band	Display / Media		
<< Tape	<< / Tune-		
>> Tape	>> / Tune+		
Stop Tape	Stop / Hold		
Play Tape	Play / Slow		
Stop CD	Rec / Rec Mode		
Play/Pause CD	Pause / Step / Freeze		

https://remotecontrols.it/Samsung/10511-759-telecomando-sostituzione-per-Samsung-AH5900004A.html