Originale		Sostituto	
	Power		Power
	Red/Sound↑	NETFLIX SEARCH	Red / Netflix / Search
	Red/Sound↑	TITLE SOUND	Sound / Title
	Green/Picture/↓	APP REPEAT	Green / APP / Repeat
	Green/Picture/↓	FORMAT PICTURE	Picture / Format
	Yellow/Feature	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue/Install	Prime Video RANDOM	Blue / Prime Video / Random
	[≡]	GOTO TEXT	Text / Goto
	[≡0]	SLOW ▶	Play / Slow
	[≡+]	HOLD ■	Stop / Hold
	[≡x]/[· ·]	STEP-FREEZE ⏸	Pause / Step / Freeze
	[/≡]/[*]	REC MODE ●	Rec / Rec Mode
	[+]([≡♦]/Wide	SIZE ZOOM	Zoom / Size
	[≡?]/PC	PC FAV MARKER	Fav / Marker / PC
	[≡i]/Guide	-/-- GUIDE EPG	Guide / EPG / -/--
1	1	TV 1	1
2	2	DVD 2	2

Originale		Sostituto	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
P<P	P<P	MEDIA DISPLAY	Display / Media
0	0	HDMI-SAT 0	0
-/-- EXIT	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
VOL -	Vol -	VOL −	Vol -
VOL +	Vol +	VOL +	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P-	P-	CH PAGE −	CH- / Page-
P+	P+	CH PAGE +	CH+ / Page+
[i]/Info		ANGLE INFO	Info / Angle
TV/DTV	TV/DTV	PROGRAM TV/RADIO	TV/Radio / Program

Originale	Sostituto	Originale	Sostituto
AV	AV / Input / RDS		
I-II	Audio / Lang I/II		
PP	Back / Return		
Up	Up		
Left	Left		
OK/Select	OK		
Right	Right		
M	Menu / Home		
Down	Down		