Mandis shop

Sony RMSCU37B

Originale	Sostituto	Originale	Sostituto
Power	Power	Pause	Pause
Sleep	Sleep	Stop	Stop
Display	Info	Clear	Exit
Clock/Timer	Format	EQ	Dual
Clock/Timer Set	3D	Folder +	Ch +
Tuner Memory	Back	Folder -	Ch -
Play Mode/Tuning Mode	Shift + Play	Vol +	Vol +
Repeat FM	Text	Vol -	Vol -
USB	Red	Enter	Ok
CD	Green		
Band/Tuner	Yellow		
Function	Blue		
I <</ -	I <<		
>>I / +	>>I		
<</ ←	<<		
>>/ →	>>		
Play	Play		

https://remote-controls.ch/it/Sony/10728-625-telecomando-sostituzione-per-Sony-RMSCU37B-A5489A.htm