Mandis shop

RM-ST1

Originale		Sostituto	
TIMER SELECT	Timer Select	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SYSTEM POWER	System Power		Power
TIMER SET	Timer Set	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
– TIMI	Timer -	CH PAGE –	CH- / Page-
MER +	Timer +	+ CH PAGE	CH+ / Page+
	Play CD/Tuner	SLOW	Play / Slow
	Pause CD/Tuner	STEP-FREEZE	Pause / Step / Freeze
	Stop CD/Tuner	SHIFT + HOLD	Shift + Stop /
BAND	Band CD/Tuner	CD-STB 3	3
– TUN	I<<</Tuning- CD/Tuner	PRESET-	I<<</ Preset-
NING +	>>I/Tuning+ CD/Tuner	PRESET+	>>I / Preset+
STEREO/ MONO	Stereo/Mono CD/Tuner	TITLE SOUND	Sound / Title
TUNING/ PLAY MODE	Tuning/Play Mode CD/Tuner	TAPE 5	5
REPEAT	Repeat	RETURN BACK	Back / Return
DISPLAY	Display CD/Tuner	MEDIA DISPLAY	Display / Media
MEMORY	Memory	TUNER 6	6

Originale		Sostituto	
ENTER	Enter	OK	OK
	< Tape	SHIFT + TUNE-	Shift + << /
	> Tape	SHIFT + TUNE+	Shift + >> /
	Stop Tape	HOLD	Stop / Hold
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT /
	<< Tape	TUNE-	<< / Tune-
	>> Tape	TUNE+	>> / Tune+
DBFB	DBFB	DVD 2	2
SURROUND	Surround	SURROUND	Eject / Surround
+ VOL	Vol +	+ VOL	Vol +
– BALAN L	Balance L		Left
ANCE – R	Balance R		Right
VOL	Vol -	VOL –	Vol -
	CD/Tuner		

https://remotecontrols.it/Sony/1330-513-telecomando-sostituzione-per-Sony-RM-ST1.htm