Mandis shop

Sony RM-SC30

Originale	Sostituto	Originale	Sostituto
Power	Power	Pause	Pause
Sleep	Sleep	Stop	Stop
Display	Info	Enter	Ok
Select	Guide	Vol +	Vol +
Set Clock/Timer	Pre Ch	Vol -	Vol -
Tuner Memory	Rec	Folder +	Ch +
Audio In	Red	Folder -	Ch -
Play Mode/Tuning Mode	Shift + Play	Clear	Exit
CD	Yellow	EQ	Options
Repeat/FM	Text		
Band/Tuner	Green		
Function	Menu		
I<<	I<<		
>>I	>>I		
<<	<<		
>>	>>		
Play	Play		

https://remotecontrols.it/Sony/1629-657-telecomando-sostituzione-per-Sony-RM-SC31-A2374.html