




















**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	Mute		Mute
	Rec		Rec
	Goto		Smart
	Aspect		3D
	V.Format		Format
	<<		<<
	>>		>>
	Play		Play
	Pause		Pause
	Stop		Stop
	Tv/Radio		TV/R
	Audio		Dual
	Dev		Options
	Recall		Back
	Red/TTX		Red
	Green/SUB.T		Green

**Originalfernbedienung    Ersatzfernbedienung**

	Yellow/Zoom		Yellow
	Blue/Option		Blue
	Info		Info
	FAV		Pre Ch
	Menu		Menu
	Exit		Exit
	Up/CH+		Up
	Down/CH-		Down
	Right/Vol+		Right
	Left/Vol-		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	SAT		Media
	EPG		Guide
	Page+		Ch +
	Page-		Ch -



