



















































Originalfernbedienung Ersatzfernbedienung

|   |            |   |        |
|---|------------|---|--------|
|    | Power      |    | Power  |
|    | 1          |    | 1      |
|    | 2          |    | 2      |
|    | 3          |    | 3      |
|    | 4          |    | 4      |
|    | 5          |    | 5      |
|    | 6          |    | 6      |
|    | 7          |    | 7      |
|    | 8          |    | 8      |
|   | 9          |   | 9      |
|  | 0          |  | 0      |
|  | Last View  |  | Pre Ch |
|  | Radio/Tv   |  | TV/R   |
|  | Internet   |  | Smart  |
|  | Netflix    |  | Media  |
|  | Rec        |  | Rec    |
|  | Prog/Check |  | Sleep  |

Originalfernbedienung Ersatzfernbedienung

|   |               |   |         |
|---|---------------|---|---------|
|    | Play          |    | Play    |
|    | >>            |    | >>      |
|    | <<            |    | <<      |
|    | Pause         |    | Pause   |
|    | >>            |    | >>      |
|    | I<<           |    | I<<     |
|    | Stop          |    | Stop    |
|    | Exit          |    | Exit    |
|    | i/Status      |    | Info    |
|   | Return        |   | Back    |
|  | Guide         |  | Guide   |
|  | Function Menu |  | Menu    |
|  | Video Menu    |  | D. Menu |
|  | Up            |  | Up      |
|  | Down          |  | Down    |
|  | Right         |  | Right   |
|  | Left          |  | Left    |



