
































Originalfernbedienung Ersatzfernbedienung

|              |   |                           |
|--------------|---|---------------------------|
| Lang./Rewind |    | << / Tune-                |
| TV           |    | TV/Radio /                |
| Epg          |  +  | Shift + Guide / EPG / -/- |
| Browse       |    | Smart / List              |
| TV/SAT       |    | AV / Input / RDS          |
| Lang./Rewind |    | Sound / Title             |
| Red          |    | Red / Netflix / Search    |
| 1. ?         |    | 1                         |
| 2abc         |    | 2                         |
| 3def         |    | 3                         |
| 4ghi         |   | 4                         |
| 5jkl         |    | 5                         |
| 6mno         |    | 6                         |
| 7pqrm        |    | 7                         |
| 8tuv         |    | 8                         |
| 9wxyz        |    | 9                         |
| Guide Pilote |    | Guide / EPG / -/-         |

Originalfernbedienung Ersatzfernbedienung

|               |   |                             |
|---------------|---|-----------------------------|
| 0/10          |    | 0                           |
| FAV Pref.     |    | Fav / Marker / PC           |
| CH/Page-      |    | CH- / Page-                 |
| Green         |    | Green / APP / Repeat        |
| Yellow        |    | Yellow / YouTube / Repeat   |
| Blue          |    | Blue / Prime Video / Random |
| Dev           |    | >>  / Preset+               |
| Freeze        |  +      | Shift + Pause / Step /      |
| Dec/Pause     |    | Pause / Step / Freeze       |
| East          |    | Rec / Rec Mode              |
| H/V Play      |   | Play / Slow                 |
| LNB F.Forward |    | >> / Tune+                  |
| Menu          |    | Menu / Home                 |
| Mute          |    | Mute / Dimmer               |
| Opt?          |    | Setup / OPT /               |
| App           |  +  | Shift + Green / APP /       |
| Info          |    | Info / Angle                |



| Originalfernbedienung | Ersatzfernbedienung   | Originalfernbedienung | Ersatzfernbedienung |
|-----------------------|---|-----------------------|---------------------|
| Subt.List             |  Subtitle / EQ   |                       |                     |
| Sleep Timer           |  Sleep / Timer   |                       |                     |
| Video                 |  +  Shift + 4 |                       |                     |
| Text                  |  Text / Goto   |                       |                     |
| Zoom                  |  Zoom / Size   |                       |                     |
| PWR On/Off            |  Power   |                       |                     |
| Menu Up               |  Up  |                       |                     |
| Menu Left             |  Left  |                       |                     |
| OK Enter              |  OK  |                       |                     |
| Menu Right            |  Right   |                       |                     |
| Exit                  |  Exit / Cancel / Clear   |                       |                     |
| Menu Down             |  Down  |                       |                     |
| Back                  |  Back / Return   |                       |                     |
| Volume+               |  Vol+  |                       |                     |
| CH/Page+              |  CH+ / Page+   |                       |                     |
| Volume-               |  Vol-  |                       |                     |
| Audio                 |  Audio / Lang I/II   |                       |                     |

