

























Originalfernbedienung Ersatzfernbedienung

|                                                                                     |       |                                                                                     |                        |
|-------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------|------------------------|
|    | Power |    | Power                  |
|    | 1     |    | 1                      |
|    | 2     |    | 2                      |
|    | 3     |    | 3                      |
|    | 4     |    | 4                      |
|    | 5     |    | 5                      |
|    | 6     |    | 6                      |
|    | 7     |    | 7                      |
|    | 8     |    | 8                      |
|    | 9     |    | 9                      |
|   | 0     |   | 0                      |
|  | AV    |  | AV / Input / RDS       |
|  | TV    |  | TV/Radio /             |
|  | I/II  |  | Audio / Lang I/II      |
|  | OO    |  | Smart / List           |
|  | Red   |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat   |

Originalfernbedienung Ersatzfernbedienung

|                                                                                       |         |                                                                                       |                             |
|---------------------------------------------------------------------------------------|---------|---------------------------------------------------------------------------------------|-----------------------------|
|    | Yellow  |    | Yellow / YouTube / Repeat   |
|    | Blue    |    | Blue / Prime Video / Random |
|    | P>P     |    | Fav / Marker / PC           |
|    | PP      |    | Back / Return               |
|    | [+]     |    | Info / Angle                |
|    | Mute    |    | Mute / Dimmer               |
|    | Up      |    | Up                          |
|    | Down    |    | Down                        |
|    | Right   |    | Right                       |
|    | Left    |    | Left                        |
|   | OK      |   | OK                          |
|  | TXT     |  | Text / Goto                 |
|  | Time    |  | Shift + Sleep / Timer       |
|  | [=i]    |  | Subtitle / EQ               |
|  | [=+]    |  | Picture / Format            |
|  | [=x]    |  | Setup / OPT /               |
|  | [ / = ] |  | Display / Media             |



