
















Originalfernbedienung Ersatzfernbedienung

|   |                |   |                             |
|---|----------------|---|-----------------------------|
|    | Standby        |    | Power                       |
|    | Mute           |    | Mute / Dimmer               |
|    | Up             |    | Up                          |
|    | Left           |    | Left                        |
|    | OK             |    | OK                          |
|    | Right          |    | Right                       |
|    | Down           |    | Down                        |
|    | Menu           |    | Menu / Home                 |
|    | Exit           |    | Exit / Cancel / Clear       |
|    | Red / UHF      |    | Red / Netflix / Search      |
|   | Green / Audio  |   | Green / APP / Repeat        |
|  | Green / Audio  |  | Audio / Lang I/II           |
|  | Yellow / Pause |  | Yellow / YouTube / Repeat   |
|  | Yellow / Pause |  | Pause / Step / Freeze       |
|  | Blue / Recall  |  | Blue / Prime Video / Random |
|  | Blue / Recall  |  | Back / Return               |
|  | 1              |  | 1                           |

Originalfernbedienung Ersatzfernbedienung

|   |       |   |                   |
|---|-------|---|-------------------|
|    | 2     |    | 2                 |
|    | 3     |    | 3                 |
|    | 4     |    | 4                 |
|    | 5     |    | 5                 |
|    | 6     |    | 6                 |
|    | 7     |    | 7                 |
|    | 8     |    | 8                 |
|    | 9     |    | 9                 |
|    | 0     |    | 0                 |
|    | EPG   |    | Guide / EPG / -/- |
|   | Group |   | Smart / List      |
|  | Vol+  |  | Vol+              |
|  | Vol-  |  | Vol-              |
|  | CH+   |  | CH+ / Page+       |
|  | CH-   |  | CH- / Page-       |
|  | Page+ |  | Shift + CH+ /     |
|  | Page- |  | Shift + CH- /     |



