



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	TV/R		TV/R
	APP		Media
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	PiP		Smart
	Vol+		Vol +

Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol -
	Back		Back
	Exit		Exit
	CH+		Ch +
	CH-		Ch -
	EPG		Guide
	Menu		Menu
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Rec		Rec
	PVR		Options
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop



