



Originalfernbedienung Ersatzfernbedienung

|   |           |   |                  |
|---|-----------|---|------------------|
|    | Power     |    | Power            |
|    | Mute      |    | Mute / Dimmer    |
|    | 1         |    | 1                |
|    | 2         |    | 2                |
|    | 3         |    | 3                |
|    | 4         |    | 4                |
|    | 5         |    | 5                |
|    | 6         |    | 6                |
|    | 7         |    | 7                |
|    | 8         |    | 8                |
|   | 9         |   | 9                |
|  | DTV / ATV |  | D.Menu / Top     |
|  | 0         |  | 0                |
|  | Recall    |  | Back / Return    |
|  | P.Mode    |  | Picture / Format |
|  | S.Mode    |  | Sound / Title    |
|  | Sleep     |  | Sleep / Timer    |

Originalfernbedienung Ersatzfernbedienung






|   |          |   |                       |
|---|----------|---|-----------------------|
|    | Vol +    |    | Vol+                  |
|    | MTS      |    | Audio / Lang I/II     |
|    | CH +     |    | CH+ / Page+           |
|    | Vol -    |    | Vol-                  |
|    | REC List |    | Smart / List          |
|    | CH -     |    | CH- / Page-           |
|    | FAV List |    | Fav / Marker / PC     |
|    | REC      |    | Rec / Rec Mode        |
|    | Freeze   |    | Pause / Step / Freeze |
|    | Menu     |    | Menu / Home           |
|   | Up       |   | Up                    |
|  | Source   |  | AV / Input / RDS      |
|  | Left     |  | Left                  |
|  | Enter    |  | OK                    |
|  | Right    |  | Right                 |
|  | Exit     |  | Exit / Cancel / Clear |
|  | Down     |  | Down                  |




**Originalfernbedienung   Ersatzfernbedienung**

|   |                        |   |                             |
|---|------------------------|---|-----------------------------|
|    | Display                |    | Display / Media             |
|    | Red                    |    | Red / Netflix / Search      |
|    | Green                  |    | Green / APP / Repeat        |
|    | Yellow                 |    | Yellow / YouTube / Repeat   |
|    | Blue                   |    | Blue / Prime Video / Random |
|    | << / Guide             |    | << / Tune-                  |
|    | << / Guide             |    | Guide / EPG / -/--          |
|    | Play/Pause / Timeshift |    | Play / Slow                 |
|    | >> / Aspect            |    | >> / Tune+                  |
|    | << / Cancel            |    | << / Preset-                |
|    | >>  / Subpage          |    | >>  / Preset+               |
|    | Stop / Index           |    | Info / Angle                |
|    | Stop / Index           |    | Stop / Hold                 |
|   | TV / Radio             |   | TV/Radio /                  |
|  | Subtitle               |  | Subtitle / EQ               |
|  | Reveal                 |  | Setup / OPT /               |
|  | Size                   |  | Zoom / Size                 |

**Originalfernbedienung   Ersatzfernbedienung**

|   |      |   |                |
|---|------|---|----------------|
|  | Hold |  +  | Shift + Stop / |
|  | Text |    | Text / Goto    |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |

