











Originalfernbedienung Ersatzfernbedienung

	AMP Power		Power
	Power		Shift + Power
	CD		Yellow
	Tuner		Green
	Network		Media
	Phono		Smart
	AUX		Red
	Recorder		Blue
	I<<<		I<<<
	>>>I		>>>I
	Stop		Stop
	Play		Play
	Pause		Pause
	Input		AV
	Info		Info
	Source Direct		3D
	Vol+		Vol +





















Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol -
	Mute		Mute
	Time/Top Menu		Menu
	Mode		Back
	Prog/Favorites		Pre Ch
	Setup		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6





Originalfernbedienung    Ersatzfernbedienung

	7		7
	8		8
	9		9
	0		0
	+10		Guide
	Clear		Exit
	Dimmer		Format
	Random		Subt
	Repeat		Text
	Search		TV/R

Originalfernbedienung    Ersatzfernbedienung






**Originalfernbedienung    Ersatzfernbedienung**

	AMP Power		Power
	Power		Shift + Power
	CD		Yellow
	Tuner		Green
	Network		Media
	Phono		Smart
	AUX		Red
	Recorder		Blue
	I<<		I<<
	Sound Mode		Dual
	>>I		>>I
	Stop		Stop
	Play		Play
	Pause		Pause
	Input		AV
	Info		Info
	Source Direct		3D

**Originalfernbedienung    Ersatzfernbedienung**

	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Time/Top Menu		Menu
	Mode		Back
	Prog/Favorites		Pre Ch
	Setup		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	1		1
	2		2
	3		3
	4		4
	5		5





**Originalfernbedienung Ersatzfernbedienung**

MNO <b>6</b>	6	<b>6</b>	6
PQRS <b>7</b>	7	<b>7</b>	7
TUV <b>8</b>	8	<b>8</b>	8
WXYZ <b>9</b>	9	<b>9</b>	9
<b>0</b>	0	<b>0</b>	0
<b>+10</b>	+10	<b>GUIDE</b>	Guide
<b>CLEAR</b>	Clear	<b>EXIT</b>	Exit
<b>DIMMER</b>	Dimmer	<b>PICTURE FORMAT</b>	Format
<b>RANDOM</b>	Random	<b>AD SUBT</b>	Subt
<b>REPEAT</b>	Repeat	<b>REPEAT TEXT</b>	Text

**Originalfernbedienung Ersatzfernbedienung**