



Originalfernbedienung Ersatzfernbedienung

	LIGHT On/Off		Power
	Fan OFF		0
	1H		Red / Netflix / Search
	2H		Green / APP / Repeat
	4H		Yellow / YouTube / Repeat
	Fan LOW		1
	Fan MED		2
	Fan HIGH		3

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung
















	Light On/Off		Power
	Fan Off		0
	1H		Red / Netflix / Search
	2H		Green / APP / Repeat
	4H		Yellow / YouTube / Repeat
	Fan LOW		1
	Fan MED		2
	Fan HIGH		3

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

















	Light On/Off		Power
	Fan Off		0
	Timer 1H		Red / Netflix / Search
	Timer 2H		Green / APP / Repeat
	Timer 4H		Yellow / YouTube / Repeat
	Fan Low		1
	Fan Med		2
	Fan High		3

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

	Light On/Off		Power
	Fan Off		0
	Timer 1H		1
	Timer 2H		2
	Timer 4H		3
	Fan LOW		Yellow / YouTube / Repeat
	Fan MED		Green / APP / Repeat
	Fan HI		Red / Netflix / Search

Originalfernbedienung Ersatzfernbedienung

