





































Originalfernbedienung Ersatzfernbedienung

|   |          |   |                    |
|---|----------|---|--------------------|
| PP  | PP       |    | Back / Return      |
|    | Power    |    | Power              |
| 1   | 1        |    | 1                  |
| 2   | 2        |    | 2                  |
| 3   | 3        |    | 3                  |
| 4   | 4        |    | 4                  |
| 5   | 5        |    | 5                  |
| 6   | 6        |    | 6                  |
| 7   | 7        |    | 7                  |
| 8   | 8        |   | 8                  |
| 9   | 9        |  | 9                  |
| P<P   | P<P      |  | Fav / Marker / PC  |
| 0   | 0        |  | 0                  |
| --  | --       |  | Guide / EPG / -/-- |
|  | Menu [M] |  | Menu / Home        |
|  | Info [i] |  | Info / Angle       |
|  | I-II     |  | Audio / Lang I/II  |

Originalfernbedienung Ersatzfernbedienung

|   |                  |   |                             |
|---|------------------|---|-----------------------------|
|    | Mute             |    | Mute / Dimmer               |
|    | Left             |    | Left                        |
|    | Up               |    | Up                          |
|    | Right            |    | Right                       |
|    | OK               |    | OK                          |
|    | Down             |    | Down                        |
|    | V -              |    | Vol-                        |
|    | V +              |    | Vol+                        |
|    | P -              |    | CH- / Page-                 |
|   | P +              |   | CH+ / Page+                 |
|  | Red / Sound      |  | Red / Netflix / Search      |
|  | Red / Sound      |  | Sound / Title               |
|  | Green / Picture  |  | Green / APP / Repeat        |
|  | Green / Picture  |  | Picture / Format            |
|  | Yellow / Feature |  | Yellow / YouTube / Repeat   |
|  | Blue / Install   |  | Blue / Prime Video / Random |
|  | Text             |  | Text / Goto                 |



