







































































Original		Replacement		Original		Replacement	
	Power		Power		CH+		Ch +
	Mute		Mute		CH-		Ch -
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Exit		Exit
	7		7		Text		Text
	8		8		Menu		Menu
	9		9		Aspect		3D
	0		0		Size		Format
	--		Guide		Sleep		Sleep
	Recall		Pre Ch		Media		Media
	Source		AV		Reveal		Options
	Vol+		Vol +		Info		Info
	Vol-		Vol -		Tv/Radio		TV/R





Original		Replacement		Original		Replacement	
	I/II/Audio		Dual		Repeat		Shift + Text
	Subtitle		Subt				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	I<<		I<<				
	>>I/INDEX		>>I				
	<</Subpage		<<				
	>>/Hold		>>				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	PIC Mode		Shift + Format				
	S.Mode		Shift + Dual				
	Rec Menu		Shift + Rec				

