












































Original	Replacement
 Power	 Power
 Power Off	 Shift + Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 _/~/Del	 Guide
 CH List	 List
 Mute	 Mute
 Source	 AV
 Vol+	 Vol +

Original	Replacement
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Home	 Smart
 Magicinfo Player 1	 Media
 Info	 Info
 Tools	 Options
 Exit	 Exit
 Return	 Back
 Enter	 Ok
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Red/PC	 Red
 Green/DVI	 Green





Original		Replacement		Original		Replacement	
	Yellow/HDMI		Yellow				
	Blue/DP		Blue				
	Set IR Control		Format				
	Unset IR Control		3D				
	Lock	 + 	Shift + Stop				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	<</ <<		<<				
	>>/>>		>>				

