



| Original | Replacement | Original | Replacement |
|---|-------------|---|-------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK/Select |  | Ok |
|  | M |  | Menu |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Guide |
|  | Exit |  | Exit |
|  | P<P/Swap |  | Pre Ch |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | PP |  | Eject |
|  | I-II |  | Dual |
|  | Tv/DTV |  | TV/R |
|  | [≡] |  | Text |
|  | [≡0] |  | Options |
|  | AV/Source |  | AV |
|  | [≡+]/[X] |  | Format |
|  | [≡X]/[■] |  | 3D |
|  | [.≡]/[■] |  | Subt |





| Original | Replacement | Original | Replacement |
|----------------|-------------|----------|-------------|
| [≡◆] | Media | | |
| [≡?] | Back | | |
| [≡i] | Info | | |
| Red/[+]/Wide/↑ | Red | | |
| Green/↓ | Green | | |
| Yellow | Yellow | | |
| Blue/Guide | Blue | | |
| [i] | D. Menu | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

