









































Original	Replacement
 Power	 Power
 Text	 Text
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -

Original	Replacement
 TV/R	 TV/R
 Exit	 Exit
 Menu	 Menu
 Back	 Back
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 APP / SAT	 Media
 EPG	 Guide
 List	 List
 Audio	 Dual





Original		Replacement		Original		Replacement	
	Sub		Subt				
	Pup		>>				
	Info		Info				
	Zoom		Eject				
	Pdw		I<<				
	FAV		Pre Ch				
	FAV+		>>				
	FAV-		<<				

