
































































Original	Replacement	Original	Replacement
 Power	 Power	 9	 9
 Mute	 Mute	 0	 0
 TV/TXT	 Text	 -/--	 Shift + Guide
 TV/AV	 AV	 Return	 Back
 FAV	 Pre Ch	 Vol+	 Vol +
 Picture	 Format	 Vol-	 Vol -
 Sound	 Dual	 OK	 Ok
 Sleep	 Sleep	 Up	 Up
 Hold	 Media	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 CH+	 Ch +
 4	 4	 CH-	 Ch -
 5	 5	 Tv Menu	 Menu
 6	 6	 EXit	 Exit
 7	 7	 Tv/Radio	 TV/R
 8	 8	 Info	 Info





	Original	Replacement	Original	Replacement
	Subtitle	 Subt		
	Audio	 D. Menu		
	EPG	 Guide		
	CH List	 List		
	Play/Pause	 Play		
	Screen	 Eject		
	Stop	 Stop		
	Record	 Rec		
	<<	 <<		
	>>	 >>		
	I<</Size	 I<<		
	>>I/Subpage	 >>I		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Blue	 Blue		

