









































































Original	Replacement	Original	Replacement
 Power	 Power	 6	 6
 Tv/TXT	 Text	 7	 7
 Input	 AV	 8	 8
 OK	 Ok	 9	 9
 Up	 Up	 0	 0
 Down	 Down	 Back	 Back
 Right	 Right	 FAV	 Shift + Pre Ch
 Left	 Left	 Menu	 Menu
 Vol+	 Vol +	 Exit	 Exit
 Vol-	 Vol -	 Nicam/A2	 Shift + Guide
 CH+	 Ch +	 Display	 Shift + Info
 CH-	 Ch -	 Mute	 Mute
 1	 1	 Picture	 Format
 2	 2	 Sound	 Dual
 3	 3	 Sleep	 Sleep
 4	 4	 Subtitle	 Subt
 5	 5	 EPG	 Guide





	Original	Replacement	Original	Replacement
	 CH/List	 Pre Ch		
	 Red	 Red		
	 Green	 Green		
	 Yellow	 Yellow		
	 Blue/Screen	 Blue		
	 Play	 Play		
	 Pause	 Pause		
	 Stop	 Stop		
	 Record	 Rec		
	 >>/Size	 >>		
	 <</Hold	 <<		
	 Cancel	 Shift + Back		
	 Reveal/Rep	 Eject		
	 I<</Subpage	 D. Menu		
	 >>I/Index	 Info		
	 List	 List		

