



| Original | Replacement |
|---|--|
|  |  Power |
|  |  AV |
|  |  Smart |
|  |  TV/R |
|  |  Eject |
|  |  Mute |
|  |  Media |
|  |  Sleep |
|  |  Dual |
|  |  Options |
|  |  Subt |
|  |  Pre Ch |
|  |  Shift + Ch - |
|  |  Shift + Ch + |
|  |  Red |
|  |  Green |
|  |  Yellow |

| Original | Replacement |
|---|--|
|  |  Blue |
|  |  Menu |
|  |  Exit |
|  |  Info |
|  |  Guide |
|  |  Up |
|  |  Down |
|  |  Right |
|  |  Left |
|  |  Ok |
|  |  Ch + |
|  |  Ch - |
|  |  Format |
|  |  Shift + Dual |
|  |  Vol + |
|  |  Vol - |
|  |  1 |





| Original | Replacement |
|-----------|-------------|
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Still | D. Menu |
| Recall | Back |
| Text | Text |
| Play | Play |
| Pause | Pause |
| <</Hold | << |
| >>/Index | >> |
| Stop/Size | Stop |

| Original | Replacement |
|------------|-------------|
| I<</Reveal | I<< |
| >>/Subpage | >>I |

