



Original	Replacement	Original	Replacement
 Power	 Power	 Mute	 Mute / Dimmer
 [112]	 Display / Media	 [-O-]	 Smart / List
 I-II	 Audio / Lang I/II	 Vol+	 Vol+
 [<>]/[+]	 Zoom / Size	 [] Smart	 Picture / Format
 AV/[?]	 AV / Input / RDS	 P+	 CH+ / Page+
 Red/Timer	 Sleep / Timer	 Vol-	 Vol-
 Red/Timer	 Red / Netflix / Search	 Smart	 Sound / Title
 Green/[]	 Green / APP / Repeat	 P-	 CH- / Page-
 Yellow/[≡]	 Yellow / YouTube / Repeat	 1	 1
 Blue	 Blue / Prime Video / Random	 2	 2
 Menu	 Menu / Home	 3	 3
 [≡]	 Text / Goto	 4	 4
 Up	 Up	 5	 5
 Left	 Left	 6	 6
 OK	 OK	 7	 7
 Right	 Right	 8	 8
 Down	 Down	 9	 9





Original	Replacement	Original	Replacement
	[i+]		Info / Angle
	0		0
	P<P		Back / Return

