
































































































































































Original	Replacement
 Power	 Power
 SD Card	 Display / Media
 Input TV	 TV/Radio /
 Input AV	 AV / Input / RDS
 Menu	 Menu / Home
 [+]/Aspect	 Picture / Format
 N	 Sound / Title
 Direct Rec TV	 Shift + Rec / Rec Mode
 i	 Info / Angle
 Exit	 Exit / Cancel / Clear
 Viera Tools	 D.Menu / Top
 Viera Link	 Smart / List
 Up	 Up
 Guide	 Guide / EPG / -/--
 Left	 Left
 OK	 OK
 Right	 Right

Original	Replacement
 Option	 Setup / OPT /
 Down	 Down
 Return	 Back / Return
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Text	 Text / Goto
 [=◆]/STTL	 Subtitle / EQ
 [=i]/Index	 Eject / Surround
 [=+]/Hold	 Shift + Stop /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6





Original	Replacement	Original	Replacement
 7	 7	 II>/Step	 Pause / Step / Freeze
 8	 8	 Rec	 Rec / Rec Mode
 9	 9		
 Mute	 Mute / Dimmer		
 0	 0		
 Recall/Last View	 Fav / Marker / PC		
 Vol+	 Vol+		
 PR+	 CH+ / Page+		
 Vol-	 Vol-		
 PR-	 CH- / Page-		
 Power Down	 Shift + Power		
 PR- Down	 Shift + CH- /		
 PR+ Down	 Shift + CH+ /		
 <</I<<	 << / Tune-		
 Play	 Play / Slow		
 >>/>>I	 >> / Tune+		
 Stop	 Stop / Hold		

Original	Replacement	Original	Replacement
 TV	 DVD	 SAT	 AUX
 SLOW	 STEP - FREEZE	 HOLD	 REC MODE
 TUNE-	 TUNE+	 PRESET-	 PRESET+
 TITLE	 LANG / III	 EQ	 SURROUND
 SOUND	 AUDIO	 SUBTITLE	 PROGRAM
 FORMAT	 SIZE	 TIMER	 TV RADIO
 PICTURE	 ZOOM	 SLEEP	 RDS
 TOP MENU	 OPT-TOOLS	 GOTO	 AV INPUT
 D.MENU	 SETUP	 TEXT	 HOME
 MENU	 ANGLE	 INFO	 RETURN
 CLEAR	 OK	 BACK	 EXIT
 CANCEL	 LIST	 SMART	 CH PAGE +
 VOL +	 MEDIA	 DISPLAY	 CH PAGE -
 TV	 DVD	 CD - STB	 TAPE
 1	 2	 3	 TUNER
 4	 5	 6	 VIDEO
 AUX - HDD	 USB	 BLUETOOTH	 Mandis
 7	 8	 9	 AUX - HDD
 GUIDE EPG	 HDMI - BAT	 PC	 Fav Marker
 NETFLIX	 APP	 YouTube	 Prime Video
 SEARCH	 REPEAT	 REPEAT A-B	 RANDOM
 www.mandis.tv			

