



Original	Replacement
INFO [i+]/REVEAL [?]	Info / Angle
[+]	Zoom / Size
POWER	Power
<<	<< / Tune-
PLAY	Play / Slow
PAUSE	Pause / Step / Freeze
>>	>> / Tune+
SYNC MENU	D.Menu / Top
STOP	Stop / Hold
THEATRE	Picture / Format
DIGITAL	Display / Media
ANALOG	Smart / List
SUBTITLE [...]	Subtitle / EQ
AUDIO	Audio / Lang I/II
GUIDE	Guide / EPG / -/--
^	Up
Source	AV / Input / RDS

Original	Replacement
<	Left
OK	OK
>	Right
RETURN	Back / Return
V	Down
Tools	Setup / OPT /
Menu	Menu / Home
RED	Red / Netflix / Search
GREEN	Green / APP / Repeat
YELLOW	Yellow / YouTube / Repeat
BLUE	Blue / Prime Video / Random
1	1
2	2
3	3
4	4
5	5
6	6





	Original	Replacement	Original	Replacement
	7			
	8			
	9			
	TEXT [=]			
	0			
	FAV			Shift + Fav / Marker / PC
	VOL+			Vol+
	CH+			CH+ / Page+
	VOL-			Vol-
	CH-			CH- / Page-
	MUTE			Mute / Dimmer
	RECALL			Fav / Marker / PC

