





































































Original		Replacement		Original		Replacement	
	Power		Power		[...]		Subt
	Input		AV		Red		Red
	Digital/Analog		D. Menu		Green		Green
	Audio		Dual		Yellow		Yellow
	[+]		3D		Blue		Blue
	Sync Menu		Menu		Guide		Guide
	1		1		[i]/[?]		Info
	2		2		Return		Back
	3		3		Options		Options
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Home		Smart
	0		0		Vol+		Vol +
	[≡]/Text		Text		Vol-		Vol -



