







































































Original	Replacement	Original	Replacement
	Power		Power
	Netflix		Media
	TV		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Eco		3D
	Source		AV
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	Info		Info
	Option		Options
	Smart TV		Smart
	Guide		Guide
	Menu		Menu
	Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Exit		Exit
	Zoom+		Shift + Ch +
	Zoom-		Shift + Ch -





Original		Replacement	
	List		List
	Sleep		Sleep
	PRE-CH		Pre Ch
	FAV	+	Shift + Pre Ch
	Rec		Rec
	I<		I<<
	Stop		Stop
	Play		Play
>I button icon"/>	>I		>>I
<< button icon"/>	<<	<< button icon"/>	<<
	Pause		Pause
>> button icon"/>	>>		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Lang		Dual

Original		Replacement	
	Subtitle		Subt
	Text		Text

