







































































Original	Replacement	Original	Replacement
	Power		Power
	AV Mode		AV / Input / RDS
	Radio		TV/Radio /
	Surround		Eject / Surround
	DTV		Shift + TV/Radio / Program
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	Vol+		Vol+
	4		4
	5		5
	6		6
	Vol-		Vol-
	7		7
	8		8
	9		9
	PR+		CH+ / Page+
	Recall		Back / Return
	0		0
	Source		Shift + AV / Input / RDS
	PR-		CH- / Page-
	[<>]		Picture / Format
	I/II/I+II		Zoom / Size
	[i+]		Info / Angle
	Sleep		Sleep / Timer
	EPG		Guide / EPG / -/--
	ESG		Setup / OPT /
	DTV Menu		Shift + D.Menu / Top Menu
	[≡]/Text		Text / Goto
	Up		Up
	Menu		Menu / Home
	Left		Left
	OK		OK





Original	Replacement	Original	Replacement
	Right		
	Exit / Cancel / Clear		
	Down		
	Shift + Back / Return		
	Shift + Info / Angle		
	Stop / Hold		
	Subtitle / EQ		
	D.Menu / Top		
	Red / Netflix / Search		
	Green / APP / Repeat		
	Yellow / YouTube / Repeat		
	Blue / Prime Video / Random		

