
















































































































Original		Replacement		Original		Replacement	
	Power		Power		Zoom		WIDE
	Open/Close		P/C / FAV		Camera/Digest		OPT+
	1		1		Title/PBC		BACK
	2		2		Menu/RTN		MENU
	3		3		I<</Prev/AF		First
	4		4		>>I/Next/Text		Last
	5		5		<</FR/SR		Rewind
	6		6		>>/FF/SF		Fast Forward
	7		7		Play/Pause/Eon		Play
	8		8		Stop/PTY		Stop
	9		9		>I</Step		Pause
	0		0		Setup		MEDIA
	Clear		EXIT		Up		UP
	Sub-T		Subt.		Down		DOWN
	On/Off		TV/R		Right		RIGHT
	Audio		Audio		Left		LEFT
	A-B		Shift + OPT+		Sel		OK





Original	Replacement
 Vol+	 VOL +
 Vol-	 VOL -
 Mute	 MUTE
 Preset+	 CH +
 Preset-	 CH -
 Marker	 Shift + MEDIA
 Display	 INFO
 Shuffle	 SRC
 Repeat	 TEXT
 Prog	 VOD
 T-Tone	 Shift + TV/R
 Surr	 Shift + Audio
 Memory	 Rec
 Tunning+	 Shift + CH +
 Tunning-	 Shift + CH -
 Door	 -/-- / EPG
 CD/DVD	 Blue (D)

Original	Replacement
 AV	 Red (A)
 Tuner	 Green (B)
 Optical	 V-FOR
 Coaxial	 Yellow (C)

