











































































Original	Replacement
 Power	 Power
 3D	 3D
 TV	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Eco	 Shift + 3D
 Source	 AV
 Vol+	 Vol +
 Vol-	 Vol -

Original	Replacement
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 Info	 Info
 Option	 Options
 Smart TV	 Smart
 Guide	 Guide
 Menu	 Menu
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Exit	 Exit
 @/Home	 Media
 Zoom-	 Shift + Ch -





Original		Replacement		Original		Replacement	
	Zoom+		Shift + Ch +		<<		<<
	Sleep		Sleep		Rec		Rec
	PRE-CH		Pre Ch		>>		>>
	FAV		Shift + Pre Ch				
	List		List				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	OO Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	>I		>>I				

