











































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Tv/Av	 AV	 ←PR	 Back
 Tv/Radio	 TV/R	 Mute	 Mute
 Freeze	 Pause	 Exit	 Exit
 Info	 Info	 Menu	 Menu
 FAV	 Pre Ch	 EPG	 Guide
 [↔]	 Format	 OK	 Ok
 Scan	 Smart	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 Red	 Red
 5	 5	 Green	 Green
 6	 6	 Position	 3D
 7	 7	 Yellow	 Yellow
 8	 8	 Text	 Text
 9	 9	 Blue	 Blue





Original		Replacement	
	Audio		Dual
	Audio L/R		Subt
	↑		Ch +
	↓		Ch -

