







































































Original	Replacement	Original	Replacement
 Power	 Power	 Mute	 Mute
 Netflix	 Media	 [i]	 Info
 TV	 TV/R	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 *	 Menu
 3	 3	 Home	 Smart
 4	 4	 Guide	 Guide
 5	 5	 ≡	 Options
 6	 6	 ↶	 Back
 7	 7	 ▲	 Up
 8	 8	 ▼	 Down
 9	 9	 ▶	 Right
 0	 0	 ◀	 Left
 Eco	 3D	 OK	 Ok
 Source	 AV	 Exit	 Exit
 Vol+	 Vol +	 Zoom+	 Shift + Ch +
 Vol-	 Vol -	 Zoom-	 Shift + Ch -





Original	Replacement	Original	Replacement
 List	 List	 Pause	 Pause
 Sleep	 Sleep	 >>	 >>
 PRE-CH	 Pre Ch		
 FAV	 Shift + Pre Ch		
 Rec	 Rec		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Lang	 Dual		
 Subtitle	 Subt		
 Text	 Text		
 I<	 I<<		
 Stop	 Stop		
 Play	 Play		
 >I	 >>I		
 <<	 <<		

